

With Mo1... Always in touch!
Mo1 is a mobile telephone just for you, with a modern, ergonomic design just the right size for your hands, a keypad that's simple and easy to use, with two direct call buttons for mum and dad. The handset is simple and easy to use, with two direct call buttons for mum and dad. The handset is simple and easy to use, with two direct call buttons for mum and dad.

Before using Mo1, remember to...
...remove the screw from the rear cover of the Mo1 connectors face down and the notched corner in its place. ...insert the Mo1 in its compartment, with the gold screws in place. ...charge the battery ...position the battery in its place ...screw on the rear cover of the Mo1

SWITCHING THE PHONE ON
To switch on the telephone, press and hold the button for a few seconds.

SWITCHING THE PHONE OFF
To switch the phone off from the standby screen, press and hold the button for a few seconds.

PLACING CALLS
Using the quick-call key to place a call: The quick-call key enables you to talk to mum or dad directly without having to search for their phone numbers in the Mo1 phone book.

Press the or key to call mum or dad. Press the key to end the call. Press the key to begin the call. Use the or keys to select the contact that you want to call and select it by pressing the key. Press the key again to begin the call. Press the key to end the call.

Calling a number from the phone book:
Press the or keys to select. Use the or keys to select. Press the key to end the call.

How to make an emergency call
Emergencies do not happen very often, but if you or someone you know really needs to, you can make emergency calls. But remember: never use the emergency call button if it is not a real emergency.

1. To place an emergency call, you must be on the Mo1 standby screen.
2. Press the key .
3. An emergency icon is displayed.
4. Press the key to begin the emergency call.
5. Remember to give your name, location and a description of the emergency to the operator.
6. To end the call, press the key.

RECEIVING CALLS
Press the key to answer the call. Press the key to end the call.

RECEIVING AN SMS
Press the key to read the message. Use the or keys to move through the text received and read each line. Press the key to return to the main screen.

BROWSING THROUGH THE SMS MESSAGES
Press the key. Use the or keys to select a message you want to read. Use the or keys to move through the text and read each line.

If you want to delete the selected message, the word **DELETE** is displayed in the bottom left part of the screen. Press the key again to delete the selected message. If you do not want to delete it, the word **BACK** is displayed in the bottom right part of the screen. Press to select this option. The "handfree" speaker mode is always activated by default. To change from "handfree" speaker mode to receiver mode, press .

HANDSFREE SPEAKER
The "handfree" speaker mode is always activated by default. To change from "handfree" speaker mode to receiver mode, press .

INCREASING AND DECREASING THE SPEAKER VOLUME
Press : If you press "+", the volume increases. Press : If you press "-", the volume decreases. For silent mode, lower the volume completely. The silent mode indicator is displayed .

BLOCK-UNBLOCK KEYPAD
Block: It is automatically blocked after 1 minute of inactivity. When it is blocked, you will see .
NOTE: Calls can be answered and emergency calls can be made even when the keypad is blocked.
Unblock: Press the + keys to unblock the keypad. You will see .

GUÍA RÁPIDA/QUICK GUIDE
Imaginarium
I YOU Mo1
with by MOBILE

Con Mo1... ¡Siempre en contacto, siempre tranquilos!
Mo1 es un teléfono móvil adaptado a vosotros, con un moderno diseño ergonómico y a la medida de tus manos, con un teclado sencillo y fácil de usar, dos teclas directas para llamar a mamá y papá, altavoz "manos libres" por defecto para que no acerques el teléfono a tu oído, teléfono de emergencia siempre habilitado...

Antes de utilizar Mo1, recuerda...
...quitar el tornillo de la tapa trasera de Mo1
...insertar la tarjeta SIM en su compartimento, con los conectores dorados hacia abajo, y la esquina biselada bien orientada.
...colocar la batería en su lugar
...atornillar la tapa trasera de Mo1
...cargar la batería

ENCENDER EL TELÉFONO
Para encender el teléfono, mantén presionada la tecla durante unos segundos.

APAGAR EL TELÉFONO
Para apagar el teléfono desde la pantalla de reposo, mantén presionada la tecla durante unos segundos.

HACER LLAMADAS
Llamar a través de la tecla de llamada rápida: La tecla de llamada rápida te permitirá hablar con mamá o papá directamente, sin necesidad de buscar sus números de teléfono en la agenda de Mo1.
Pulsa la tecla o para llamar a mamá o papá.
Pulsa para comenzar la llamada.
Pulsa la tecla para finalizar la llamada.
Llamar a un número de la agenda:
Pulsa . Con las teclas o selecciona y pulsa la tecla .

¡Aprenderá la lista de los contactos que tengas guardados en el teléfono!
Con las teclas o , elige el contacto al que quieres llamar y selecciónalo pulsando la tecla .
Pulsa de nuevo la tecla para comenzar la llamada.
Pulsa la tecla para finalizar la llamada.

Hacer una llamada de emergencia:
Las emergencias no ocurren muy a menudo, pero si tú o alguien a quien conoces realmente lo necesita, puedes realizar llamadas de emergencia. Pero, recuerda: no utilices nunca el botón de llamadas de emergencia si no se trata de una verdadera emergencia.

1. Para realizar la llamada de emergencia, deberás estar en la pantalla de reposo de tu Mo1.
2. Pulsa la tecla .
3. En la pantalla aparecerá un icono de emergencia.
4. Pulsa la tecla para comenzar la llamada de emergencia.
5. Recuerda indicar tu nombre, situación y naturaleza de la emergencia al operador.
6. Para finalizar la llamada, pulsa la tecla .

RECIBIR LLAMADAS
Pulsa la tecla para responder a la llamada.
Pulsa la tecla para finalizar la llamada.

RECIBIR UN SMS
Pulsa la tecla para leer el mensaje.
Con las teclas o mueve el texto recibido para poder leer todas las líneas.
Pulsa la tecla para volver a la pantalla principal.

NAVEGAR POR LOS SMS
Pulsa la tecla . Con las teclas o selecciona y pulsa la tecla . Aparecerá la lista de SMS que hayas recibido y podrás visualizar los contactos que te enviaron SMS.
Selecciona con las teclas y el mensaje que desees y pulsa la tecla para leerlo.
Con las teclas o , mueve el texto para poder leer todas las líneas.

Si deseas borrar el mensaje seleccionado, en la pantalla abajo a la izquierda, aparece la palabra **BORRAR** vuelve a pulsar la tecla y se borrará el mensaje que hayas elegido.
Si no deseas borrarlo, en la pantalla abajo a la derecha, aparece la palabra **ATRÁS**. Pulsa para seleccionar esta opción.

ALTAVOZ MANOS LIBRES
El modo altavoz "manos libres" esta siempre activo por defecto.
Para cambiar del modo altavoz "manos libres" al modo auricular, presiona la tecla .

Si pulsas la tecla durante una llamada, pasa a modo auricular.
Pulsa de nuevo la tecla para volver al modo "manos libres".

SUBIR Y BAJAR EL VOLUMEN DEL ALTAVOZ
Pulsa . Si pulsas "+", el volumen subirá.
Si pulsas el volumen bajará.
Para el modo silencio, baja todo el volumen. En la pantalla aparecerá el indicador de modo silencio .

BLOQUEAR-DESBLOQUEAR TECLADO
Bloquear: Se bloquea automáticamente tras 1 minuto de inactividad. Cuando esté bloqueado aparecerá .

Desbloquear: Presiona las teclas + para desbloquear el teclado. Aparecerá .

NOTA: Se podrán contestar llamadas y realizar llamadas de emergencia aunque el teclado esté bloqueado.

